

Barling's Woodworks Pty. Ltd.

152 Mt Dandenong Rd Croydon Vic 3136 (03) 9724 9600. Fax (03) 9724 9466
sales@barlings.com.au www.barlings.com.au



INSTALLATION IN CONCRETE FOOTING

You can use premix Concrete delivered in a Mini mix or make your own Ready Mixed or Rapid set Concrete in a wheelbarrow.

I recommend making a small dryer mix in a barrow first to set the posts height and line before adding the remainder of concrete even if you are using delivered pre mix. once the posts are at the correct height and level you can lean them back against the edge of the hole until ready to add the remainder of concrete.

It takes time to get your posts set to the string line and leveled, its time you wont have if you leave it until the cement truck arrives. you will be rushed by the driver and will have very little time to get the posts right.

Note: POST & RAIL fences.

I recommend using a ready mix like rapid set. This way you can install the post and rails as you go. Pre mix delivery would not suit unless you set all the post and rails using and braced all the posts in position.

